

QuestMark 3095 Textured High Build Epoxy Coating

Directions for Use:

- *This product is intended to be used over an epoxy mortar troweled system.*
- *For best results, we recommend a fine brush blast to provide a suitable substrate.*
- *Ensure all dirt, oil, dust, or other debris has been removed and surface is dry.*
- *Mixing ratio is two parts A to one part B by volume. Standard kits are pre-measured for proper mixing.*
- *Mix thoroughly with slow-speed mixer until material is streak-free. Make sure to scrape the bottom and sides of pail while mixing.*
- *Apply using a flat, flexible squeegee so as to apply in a uniform manner, then backroll using a stippler texture roller.*
- *For cleanup, use xylol.*

PLEASE NOTE: This product has a usable application time of 13-23 minutes once mixed.