

QuestMark 2130 Coal Tar Epoxy Patch

Directions for Use:

- *Clean repair area removing all dirt, oil, dust or other debris.*
- *Ensure floor is dry prior to application.*
- *Mix Parts A and B together in an over-sized container until streak free.*
- *Add sand mixture and stir to a mortar consistency.*
- *Trowel on mixture at 1/8" to 1/4" thickness using a hand trowel or other suitable equipment..*
- *For cleanup, use xylol or similar product.*
- *See Technical Data Sheet for Cure Schedule.*

PLEASE NOTE: This product has a usable application time of 20-30 minutes once mixed.