

QuestMark 2343 Concrete Quick Patch

Directions for Use:

- *Clean repair area removing all dirt, oil, dust or other debris.*
- *Ensure floor is dry prior to application.*
- *This product has a 1:1 mix ratio. Mix only the amount that can be used in 1 minute if mixing by hand.*
- *Apply a thin layer of mixed liquids onto surface. If larger area, it may be beneficial to use a small brush to ensure uniform application.*
- *Sprinkle dry sand onto repair area until hole is filled and repair area is level with rest of floor surface.*
- *Trowel until smooth and remove excess material.*
- *Allow 20 minutes to cure for foot traffic, and 30-60 minutes for heavy equipment.*

PLEASE NOTE: This product has a usable application time of 1-4 minutes once mixed.