

QuestMark 3380

High Build Fast Cure Epoxy

Directions for Use:

- *A suitable primer should be used before applying. Recommended primer 1154.*
- *For best results, we recommend a fine brush blast to provide a suitable substrate.*
- *Ensure all dirt, oil, dust, or other debris has been removed and surface is dry.*
- *Exact mixing ratio is necessary, so we recommend mixing the entire kit unless proper weighing equipment is available (See Technical Data Sheet for exact mix ratio).*
- *Mix thoroughly with slow-speed mixer until material is streak-free. Transfer to another pail and mix again.*
- *Can be applied using a roller or brush, or using a serrated squeegee and back rolling onto surface.*
- *For cleanup, use xylol.*

PLEASE NOTE: This product has a usable application time of 22-32 minutes once mixed. Because of the short usable life, we recommend only mixing an amount that can be applied in that time.