

QuestMark 5821

Low Modules Fast Set Gel

Directions for Use:

- *Clean repair area removing all dirt, oil, dust or other debris.*
- *Ensure floor is dry prior to application.*
- *Measure out equal volumes of Part A and Part B.*
- *Mix thoroughly with slow speed mixing equipment such as a jiffy mixer, putty knife, or trowel until material is uniform in color.*
- *Apply using a marginal trowel or putty knife.*
- *For Cleanup, use xylol or similar product.*

PLEASE NOTE: This product has a usable application time of 7-10 minutes once mixed, so it is recommended that smaller volumes are mixed and worked with to maximize usable life.