



QuestMark 5831

Polyurea Flexible Control Joint Filler

Directions for Use:

- *Clean control joint removing all dirt, oil, dust or other debris.*
- *Ensure area is dry prior to application.*
- *For bulk mixing, use a 1 to 1 ratio pump.*
- *Only component "B" must be stirred before loading into pump.*
- *Excess cured material may be stripped or peeled from repair area as well as plastic tools and containers.*

PLEASE NOTE: Don not allow material to reside in static mixing head or nozzle for longer than 45 seconds. Material is also pourable and self-leveling with a usable life (for 4 oz) of 1-2 minutes once mixed.