

QuestMark 8256 Novolac Epoxy Coating (CLEAR)

Directions for Use:

- *A suitable primer should be used before applying. We recommend primer 8258.*
- *For best results, we recommend a fine brush blast to provide a suitable substrate.*
- *Ensure all dirt, oil, dust, or other debris has been removed and surface is dry.*
- *Exact mixing ratio is necessary, so we recommend mixing the entire kit unless proper weighing equipment is available (See Technical Data Sheet for exact mix ratio).*
- *Mix thoroughly with slow-speed mixer until material is streak-free. Transfer to another pail and mix again.*
- *Can be applied using a roller or brush, or using a serrated squeegee and back rolling onto surface.*
- *For cleanup, use xylol.*

PLEASE NOTE: This product has a usable application time of 30-40 minutes once mixed.