

## QuestMark 8257 Novolac Epoxy Primer

### Directions for Use:

- *A suitable primer should be used before applying. Suitable primers include 8253 and 8253SL.*
- *For 1-2 coat system, we recommend either a mechanical scarification or acid etching.*
- *For higher build, we recommend a fine brush blast.*
- *Ensure all dirt, oil, dust, or other debris has been removed and surface is dry.*
- *Exact mixing ratio is necessary, so we recommend mixing the entire kit unless proper weighing equipment is available (See Technical Data Sheet for exact mix ratio).*
- *Mix thoroughly with slow-speed mixer until material is streak-free.*
- *Can be applied using a roller or brush.*
- *For cleanup, use xylol.*

**PLEASE NOTE: This product has a usable application time of 1-3 hours once mixed.**