

QuestMark 3707OP

High Build Epoxy Coating - Orange Peel

Directions for Use:

- *A suitable primer should be used before applying. Suitable primers include 1015, 1144.*
- *For best results, we recommend a fine brush blast to provide a suitable substrate.*
- *Ensure all dirt, oil, dust, or other debris has been removed and surface is dry.*
- *Mixing ratio is two parts A to one part B by volume. Standard kits are pre-measured for proper mixing.*
- *Mix thoroughly with slow-speed mixer until material is streak-free. Transfer to another pail and mix again.*
- *Can be applied using a roller or brush, or using a serrated squeegee and back rolling onto surface.*
- *For cleanup, use xylol.*

PLEASE NOTE: This product has a usable application time of 30-50 minutes once mixed.