

## QuestMark 5829 Flexible Joint Sealant

### Directions for Use:

- *Remove all loose concrete, previous joint compounds, or other foreign materials leaving a clean, sound joint at least 2" deep.*
- *We recommend a 1" backer rod be placed in the joint.*
- *Measure out equal volumes of Part A and Part B.*
- *Mix thoroughly using a slow speed mixer until material is streak free.*
- *Pour material into the expansion joint, removing any excess with a putty knife.*
- *For Cleanup, use xylol or similar product.*

**PLEASE NOTE: This product has a usable application time of 30-40 minutes once mixed.**