

## QuestMark 8120SL

### Chemical Resistant Self Leveling Epoxy Resurfacer

#### Directions for Use:

- *A suitable primer should be used before applying. Suitable primers include 1015, 1144.*
- *Clean repair area removing all dirt, oil, dust or other debris.*
- *Ensure floor is dry prior to application.*
- *Mix Parts A and B together thoroughly.*
- *Add sand mixture and stir to a mortar consistency.*
- *Material can be applied using a serrated squeegee to desired thickness, and then lightly back rolled using a conventional roller.*
- *For cleanup, use xylol.*

**PLEASE NOTE: This product has a usable application time of 30-40 minutes once mixed.**