

## QuestMark 8250

## Premium Novolac Epoxy Resurfacer

## **Directions for Use:**

- Clean repair area removing all dirt, oil, dust or other debris.
- Ensure floor is dry prior to application.
- Mix Parts A and B together in an over-sized container until streak free.
- Add sand mixture and stir to a mortar consistency.
- Trowel on mixture at 1/8" to 1/4" thickness using a hand trowel or other suitable equipment.
- For cleanup, use xylol or similar product.
- See Technical Data Sheet for Cure Schedule.

PLEASE NOTE: This product has a usable application time of 40-60 minutes once mixed.