

## QM Urethane Patch

### Directions for Use:

- *Repair area must be clean, oil free, dry, and sound.*
- *To ensure full bonding, we recommend the edges of the floor area adjoin the walls be keyed to create a cross section running at 6" from and parallel to the wall .*
- *Resin and hardener should be blended in an over-sized container for 30 seconds.*
- *Gradually add aggregate until mortar consistency is achieved.*
- *Trowel on mixture at 1/8" to 1/4" thickness using a hand trowel or other suitable equipment.*
- *Back roll using 3/8" nap roller to eliminate trowel marks.*
- *For cleanup, use xylol or similar product.*
- *See Technical Data Sheet for Cure Schedule.*

**PLEASE NOTE: This product has a usable application time of 15 minutes once mixed.**